

EQ SMART-LEVEL OPERATION - TRAILER VERSION

Park unit, use the switch(s)* for the front jacks to disconnect the trailer from the tow vehicle.

The front jacks must be planted on the ground supporting the trailer. The tow vehicle must be out from under the trailer before performing auto level functions. Use the switch(s)* for the front jacks to adjust the front so that the front is

Use the switch(s)* for the front jacks to adjust the front so that the front is not "excessively" high or low.

Press the **POWER** button on the eq **SMART-LEVEL KEYPAD/EQ SMART-LEVEL APP** to turn the system on.

If the rear jacks down are lit in the center of the keypad, press **ALL RETRACT**. When the rear lights go out press **AUTO LEVEL**. During the leveling process the keypad will beep.

Allow **EQ SMART-LEVEL** system to run in the auto mode until all jacks are finished adjusting.

At this time you will hear two beeps indicating you are level and the process is complete. Press the **POWER** button on the eq **SMART-LEVEL KEYPAD/EQ SMART-LEVEL APP** to turn the system off.

RETRACTING LEVELING SYSTEM

When you are ready to move your trailer, press the **POWER** button and then press the **ALL RETRACT** button.

This will retract only the rear jacks. When the rear jacks are fully retracted the two rear jacks down status lights will go out and the beeping will stop.

Use the switch(s)* for the front jacks to connect to the tow vehicle then fully retract the front jacks. Once you're finished, press power to turn off.

Visually inspect to be sure that all jacks are fully retracted prior to travel.

*Front jacks on trailer systems may be operated from the manual control switch(s) on the EQ SMART -LEVEL keypad or from the optional dual leg switch assembly for the front iacks.

BLUETOOTH OPERATION

- If the face of your keypad indicates that your controller is compatible with a bluetooth device, Download the **EQ SMART -LEVEL APP** in the Android or Apple app store.
- If your keypad does not indicate compatibility, your Bluetooth connectivity may be done through your multiplex system. When downloading the app, make sure your Bluetooth setting is turned on or the app will not connect to your coach.

Once the app is downloaded please follow the instructions above to level your coach.

PREVENTATIVE MAINTENANCE

- Make sure that all battery and electrical connections are tight and free of corrosion.
- Verify that the batteries are good and properly charged.
- Depending on how often the jack shafts are exposed to the outdoor elements, it is good to keep them coated with a silicone based lubricant.
- Do not use grease or any other lubricant that stays wet.
- In the event that it is necessary to add fluid to the reservoir, use a good quality automatic transmission fluid (Dexron).





FOR RECALIBRATION/SETTING THE NULL

please view the video in the Support section of our website.



FOR MANUAL OVERRIDE OF THE RETRACT FUNCTION

please view the video in the Support section of our website.



(800) 846-9659

For a complete operation and troubleshooting manual or to activate your warranty please visit **EQSYSTEMS.US**